


# L.U.C.A.S 600 System Connection Guide



**REMEMBER**

Turn amplifier on last, but off first..!



Limit Indicator  
Avoid RED

Limit Indicator  
Avoid RED

Subwoofer  
Volume  
Set To  
12 o'clock

Loudspeaker Volumes  
Set To Full  
(LEFT & RIGHT)

This is where your  
DJ Console or  
Sound Mixer  
plugs in (LEFT)

This is where your  
DJ Console or  
Sound Mixer  
plugs in (RIGHT)

This is where you  
plug in the power  
connector.

This is where the  
loudspeaker  
lead is connected  
(LEFT)

Turn on/off  
switch

This is where the  
loudspeaker  
lead is connected  
(RIGHT)