

# SOUND/PA SYSTEM (Switch on/off procedure)

To switch off equipment

- 1 Connect **ALL** equipment together checking that **ALL** power switches are **OFF**
- 2 Once all connections are made switch on equipment as follows.
- 3 If you have a twin cd console or twin turntables and mixer switch them on **FIRST**.
- 4 If you have an active pa system (amps built in) switch them on **LAST**.
- 5 If you have a separate power amp switch it on **LAST**.
- 6 Make sure you **DON'T** switch on in the wrong order as this can damage the equipment.
- 7 Proceed on to use equipment.

To switch off equipment

- 1 Switch off active speaker system or power amp **FIRST**
- 2 Leave for about 30 seconds then switch off all other equipment.